

- SUPPLIES NEEDED**
- 3 YARDS OF 54" WIDE FABRIC
  - SHARP SCISSORS
  - REMOVABLE MARKING MEDIUM (chalk, wax, tailor's tack, etc.)
  - 1 - 24" NON-SEPARATING ZIPPER
  - THREAD
  - SEWING MACHINE
- OPTIONAL**
- 1/2 YARD OF THINNER POCKET FABRIC

**CUTTING INSTRUCTIONS**

- Print pattern. You can print this document (and on sheets of standard size paper and tape the pieces together, or print on a wide-format printer (36" or wider). Print sheets offer this service for approximately \$12. If available to you, the B50 recommended wide-format printing.
- Once your pattern is printed, cut along the outermost rectangle to remove any excess paper. This template should fit exactly on a 36" wide or larger piece of fabric that has been folded in half. If your fabric is less than 36" wide:
- NOTE A:** For maximum yield this pattern is laid out for fabric that does not have a direction. If for fabric with a nap, such as velvet or corduroy or fabric with a clear directional print, use **NOTE B**.
- Tape your fabric in half along the lengthwise grain matching selvage edge to selvage edge. Schedule in the self-finished edge of fabric. This serves to keep the fabric from stretching or fraying. When it has an edge that overflows any fringe, though not as frequently, a clearly finished line will be found. Avoid this edge in your cut pieces as the seam frequently differs from the main body of the fabric.
- Place the paper template on top your fabric, matching the folded edge of the fabric with the side of the paper marked "folded edge".
- Place pins throughout the template pinning together both layers of fabric as well as the paper.
- Leaving the pins in place, you will need to strip each of the numbers, taking care to not strip beyond the end of the 1/2 object.
- Notice any **1/2** shaped markings that are found throughout the pattern. Some markings indicate seam allowances, while others will help you to align your pieces while sewing.
- Mark all interior darts, hems, or markings, as indicated by the following symbols:  
They will be found on the Outer Back, Under Back, and Front pieces.
- Your marker will help, or markings, are indicated by the following symbols:  
They will be found on the Outer Back, Under Back, and Front pieces.
- Remove all cut fabric markings once you **NOTE C** for more info. Pattern pieces that use fusible will be marked with the dimension "Cut 2 Fusible" or "Cut 1 Fusible". These pieces are the Collar, Fly, Fly Facing, Front Pocket Facing, and Front Pocket Bagging. To cut the fusible, lay the material down with the glue side facing up, then place your pattern down and cut around the perimeter of each piece and notch.
- Use the Front Pocket Bagging cut of a lighter packing material. If you are not using a packing material, then the Front Pocket Bagging may be cut alongside your other pattern pieces. **Pushing it out in either half in case of thicker material** - You will find an example of packing in our part of the page.

**NOTE A: FABRIC LESS THAN 34" WIDE**

If your fabric is less than 34" wide you will need to cut each pattern piece individually from the paper template and piece them together. This is not recommended. The paper template and markings are on a 36" wide or larger piece of fabric for ease of use. To find the greatest marking fit for the length of your fabric, use the markings on each pattern piece for ease of use. To find the greatest marking fit for the length of your fabric, use the markings on each pattern piece for ease of use.

**NOTE B: FABRIC WITH NAP OR DIRECTIONAL PATTERN**

For fabric with a nap such as velvet or corduroy, fabric with a clear directional print, or with markings such as a plaid, you will need to cut the pattern pieces individually. To do this, lay your fabric flat, ensuring the selvedge side is on the right. Then, measure the distance, in inches, of each pattern piece for ease of use. To find the greatest marking fit for the length of your fabric, use the markings on each pattern piece for ease of use.

**NOTE C: USING FUSIBLE INTERFACING**

Fusible interfacing is used to stabilize pattern pieces in garments. When the use of fusible interfacing is required, the pattern pieces will be marked with the dimension "Cut 2 Fusible" or "Cut 1 Fusible". To cut the fusible, lay the material down with the glue side facing up, then place your pattern down and cut around the perimeter of each piece and notch.

